

Zebra ZebraZPLII Driver

Filename	ZebraZPLII.dll
Manufacturer	Zebra Technologies Corporation
Devices	Zebra printers supporting ZPL II or EPL II language
Protocol	Zebra Programming Language II (ZPL II) and EPL II
Version	3.0.2
Last Update	06/18/2021
Platform	Win32
Dependencies	IOKit v1.15 or later
Superblock Reading	No
Level	0

Introduction

This Driver was initially developed to allow communication between **Elipse Software** systems and Zebra printers via ZPL II protocol or language. Since its implementation is rather generic, it was later discovered that it can also be used with printers supporting EPL II language. This Driver has not been tested with other languages yet, although they are likely supported by it too.

Since version 2.0 of this Driver, part of its functionality is shared with the **IOKit** component, which allows an easier, more versatile configuration, including the possibility of communication via Ethernet interface, supported by some new printer models. For more information about the **IOKit** library, please check topic **Documentation of I/O Interfaces**.

Driver Settings

The examples in this section refer only to the use of ZPL II language, but using EPL II language is analogous.

To use this Driver, users must create a configuration file in ZPL II (*Zebra Programming Language II*) format containing the description of the labels to print. To create this file, open this Driver's **Extra** settings window, **Other Parameters** in **E3** or in **Elipse Power**, and click the **ZebraZPLII** tab.

Each label must start with the keyword **[BEGIN]** and end with the keyword **[END]**. Inside these blocks, defined by these two keywords, there must be a user-created ZPL II program describing the label to generate.

Users can create variables identified by tokens, which are replaced during the printing process. A token is composed by $&n$, where n is a positive integer, such as $&0$, $&1$, or $&2$. These variables can be defined in an **E3** or **Elipse Power** application using a PLC Tag with its $N1$ parameter equal to 0 (zero), as described later in this manual, and can contain numbers and also **Strings**.

To insert comments in ZPL code, use the expression `"/"` (double slash marks), which considers as a comment the rest of the line.

The next example was copied from ZPL II Language Programming Guide.

```

//Label 0:
[BEGIN]
^XA
//^XA - Indicates the start of label formatting
^LH&0,&1
//^LH - Sets label's initial position to
//&0 dots to the right and &1 dots starting
//from label's top edge
//( &0 and &1 are variables defined in the application at printing time)
^FO&2,&3^AD^FDZEBRA^FS
//^FO&2,&3 - Set field's origin to
//&2 dots to the right and &3 dots down starting
//from initial position (defined by the ^LH instruction)
//( &2 and &3 are variables)
//^AD - Selects a "D" font
//^FD - Start of field data
//ZEBRA - Actual field data (the word "ZEBRA")
//^FS - End of field data
^FO&4,&5^B3^FDAAA001^FS
//^FO&4,&5 - Sets field origin to
//&4 dots to the right and &5 dots down
//from the initial position (defined by the ^LH instruction)
//( &4 and &5 are variables)
//^B3 - Selects the bar code font "Code 39"
//^FD - Start of field data for the bar code
//AAA001 - Actual field data ("AAA001")
//^FS - End of field data
^XZ
//^XZ - Indicates end of label formatting
[END]

```

In the previous example, only the characters without the initial expression "//" are sent to the printer. All tokens beginning with "&" are replaced by one of this Driver's internal variables, from 0 (zero) to 50, which can be read and written with PLC Tags with their *N1* parameter equal to 0 (zero). The initial value, before any operation, of all variables is equal to -1 (minus one), so users must initialize a variable whenever needed.

Several labels can be defined in the same file. The order each label appears in this configuration file is used to select it when printing, by using the *N2* parameter of a PLC Tag with its *N1* parameter equal to 1 (one), starting with 0 (zero), that is, the first label is 0 (zero), the second label is 1 (one), and so on.

This Driver, when loaded in a new project, is already pre-configured with the following parameters:

- **Serial port:** Com1
- **Baud rate:** 9600bps
- **Data bits:** 7 (seven)
- **Stop bits:** 2 (two)
- **Parity:** Even
- **Timeout:** 1000ms

To edit these settings, as well as for other settings, use this Driver's extra parameters window. The available options on this window are described on topic **Documentation of I/O Interfaces**.

[P] Parameters for Driver Communication

P1	Not used, leave it in 0 (zero)
P2	Not used, leave it in 0 (zero)
P3	Not used, leave it in 0 (zero)
P4	Not used, leave it in 0 (zero)

[N] Parameters for PLC Tags

N1	Function. Possible values are 0 : Reading or writing internal variables or 1 : Label printing
N2	Please check the next table
N3	Please check the next table
N4	Please check the next table

The *N2*, *N3*, and *N4* parameters vary according to the function indicated in the *N1* parameter, as described on the next table.

[N] parameters according to printer's functions

PARAMETER	N1 EQUAL TO 0 (ZERO)	N1 EQUAL TO 1 (ONE)
N2	Number of the variable, from 0 (zero) to 50	Number of the label to print. Possible values are 0 : 1st label, 1 : 2nd label, and so on
N3	Not used	Number of decimal places to print. Possible values are 0 : No decimal places, 1 : 9.9, 2 : 9.99, and so on
N4	Not used	Not used

Notes

- Tags with the *N1* parameter equal to 1 (one, label printing) must be read-only.
- All numbers are rounded for printing, adjusting to what is set in the *N3* parameter.
- The *&n* tokens (*&1*, *&2*, *&3*, *&4*, etc.) are replaced by the values defined in the variables of an **E3** or **Eclipse Power** application at printing time.
- Starting with version 1.1 of this Driver, in addition to numbers, users can also define **Strings** as values of internal variables.
- All internal variables used must be necessarily initialized before printing.


Documentation of I/O Interfaces

This section contains the documentation of I/O Interfaces referring to the **ZebraZPLII** Driver.

Driver Configuration

I/O Interface configuration is performed on a Driver's configuration dialog box. To access the configuration of this dialog box in **E3** (version 1.0), follow these steps:

1. Right-click a Driver object (IODriver).
2. Select the **Properties** item on the contextual menu.
3. Select the **Driver** tab.
4. Click **Other parameters**.

In **E3** version 2.0 or later, click **Configure driver**  on a Driver's toolbar. In **Elipse SCADA**, follow these steps:

1. Open the Organizer.
2. Select a Driver on Organizer's tree.
3. Click **Extras** on the **Driver** tab.

Currently, an I/O Interface allows opening only one connection for each Driver. This means that, if users want to access two serial ports, they must add two Drivers to an application and then configure each Driver for each serial port.

Configuration Dialog Box

The I/O Interfaces dialog box allows configuring the I/O connection used by a Driver. This dialog box contains the **Setup**, **Serial**, **Ethernet**, **Modem**, and **RAS** tabs, described on the next topics. If a Driver does not implement a specific I/O connection, its corresponding tab is not available for configuration. Some Drivers may contain additional tabs, specific for each Driver, on the configuration dialog box.

Setup Tab

The **Setup** tab contains Driver's general configurations. This tab is divided into the following groups:

- **General configurations:** Configurations of Driver's physical layer, time-out, and initialization mode
- **Connection management:** Configurations on how the I/O Interface keeps a connection and which recovery policy is used on failure
- **Logging options:** Controls the generation of log files

Setup

Physical Layer: Serial Start driver OFFLINE

Timeout: 1000 ms

Connection management

Mode: Automatic (managed by the driver)

Retry failed connection every 20 seconds

Give up after 1 failed retries

Disconnect if non-responsive for 0 seconds

Logging Options

Log to File: C:\eeLogs\Modbus_%.DATE%.log

Setup tab

General options on the Setup tab

OPTION	DESCRIPTION
Physical Layer	Select the physical layer on a list. Available options are Serial , Ethernet , Modem , and RAS . The selected interface must be configured on its specific tab
Timeout	Configure a time-out, in milliseconds, for the physical layer. This is the amount of time an I/O interface waits to receive any byte from reception's buffer
Start driver OFFLINE	Select this option so that the Driver starts in Offline mode or stopped. This means that the I/O interface is not created until this Driver is configured to Online mode by using a Tag in an application. This mode enables a dynamic configuration of an I/O interface at run time

Options on the Connection management group

OPTION	DESCRIPTION
Mode	Selects a management mode of a connection. Selecting the Automatic option allows a Driver to manage the connection automatically, as specified in the next options. Selecting the Manual option allows an application to fully manage a connection. Please check topic Driver Statuses for more details
Retry failed connection every ... seconds	Select this option to enable a Driver's connection retry in a certain interval, in seconds. If the Give up after failed retries option is not selected, the Driver keeps retrying

OPTION	DESCRIPTION
	until a connection is performed, or until the application is stopped
Give up after ... failed retries	Enable this option to define a maximum number of connection retries. When the specified number of consecutive connection retries is reached, the Driver goes to the Offline mode, assuming that a hardware problem was detected. If a Driver establishes a successful connection, the number of unsuccessful retries is cleared. If this new connection is lost, then the retry counter starts at zero
Disconnect if non-responsive for ... seconds	Enable this option to force a Driver to disconnect if no byte was received by the I/O interface during the specified time-out, in seconds. This time-out must be greater than the time-out configured in the Timeout option

Options on the Logging Options group

OPTION	DESCRIPTION
Log to File	<p>Enable this option and configure the name of a file to write a log. Log files can be large, so use this option for short periods of time, only for testing and debugging purposes.</p> <p>If the %PROCESS% macro is used in the log file name, it is replaced by the ID of the current process. This option is particularly useful when using several instances of the same Driver in E3, thus allowing each instance to generate a separate log file. For example, when configuring this option as c:\e3logs\drivers\sim_%PROCESS%.log, a file named c:\e3logs\drivers\sim_0000FDA.log is generated for process 0FDAh.</p> <p>Users can also use the %DATE% macro in the file name. In this case a log file is generated every day (in the format aaaa_mm_dd). For example, when configuring this option as c:\e3logs\drivers\sim_%DATE%.log, a file named c:\e3logs\drivers\sim_2005_12_31.log is generated in 12/31/2005 and a file named c:\e3logs\drivers\sim_2006_01_01.log is generated in 01/01/2006</p>

Serial Tab

Use this tab to configure parameters for a **Serial** Interface.

Serial

Port:

Baud rate:

Data bits:

Parity:

Stop bits:

Enable 'ECHO' suppression

Handshaking

DTR control:

RTS control:

Wait for CTS before send

CTS timeout: ms

Delay before send: ms

Delay after send: ms

Inter-byte delay (microseconds): μ s

Inter-frame delay (milliseconds): ms

Serial tab

General options on the Serial tab

OPTION	DESCRIPTION
Port	Select a serial port on the list, from COM1 to COM4 , or type the name of a serial port in the format COMn , such as "COM15". When typing a port's name manually, the dialog box only accepts port names starting with the expression "COM"
Baud rate	Select a baud rate on the list (1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200) or type a baud rate, such as 600
Data bits	Select 7 (seven) or 8 (eight) data bits on the list
Parity	Select a parity on the list. The available options are None, Even, Odd, Mark, or List
Stop bits	Select the number of stop bits on the list. The available options are 1, 1.5, or 2 stop bits
Enable 'ECHO' suppression	Enable this option to remove the echo received after the I/O Interface sends data via serial port. If this echo is not equal to the bytes just sent, then the I/O Interface aborts communication.
Inter-byte delay (microseconds)	Defines a delay between each byte transmitted by the I/O Interface, in millionths of a second, that is, 1000000 is equal to a second. This option must be used with small delays of less than a millisecond
Inter-frame delay (milliseconds)	Defines a delay between packets sent or received by the I/O Interface, in thousandths of a second, that is, 1000 is equal to a second. This delay is applied if the I/O Interface

OPTION	DESCRIPTION
	sends two consecutive packets, or between a received packet and the next sending

The **Handshaking** group configures the usage of **RTS**, **CTS**, and **DTR** signals in the handshaking process (controlling when data can be sent or received via serial line). Most of the time, configuring the **DTR control** option to **ON** and the **RTS control** option to **Toggle** works with RS232 serial lines as well as with RS485 serial lines.

Available options on the Handshaking group

OPTION	DESCRIPTION
DTR control	Select ON to keep the DTR signal always on while the serial port is open. Select OFF to turn the DTR signal off while the serial port is open. Some devices require the DTR signal always on to allow communication.
RTS control	Select ON to keep the RTS signal always on while the serial port is open. Select OFF to turn the RTS signal off while the serial port is open. Select Toggle to turn the RTS signal on while sending bytes via serial port and turn it off when not sending bytes, therefore enabling the reception.
Wait for CTS before send	Available only when the RTS control option is configured to Toggle . Use this option to force a Driver to check the CTS signal before sending bytes via serial port, after turning the RTS signal on. In this mode the CTS signal is handled as a permission flag for sending.
CTS timeout	Determines a maximum time, in milliseconds, that a Driver waits for the CTS signal after turning the RTS signal on. If the CTS signal is not turned on within this time-out, the Driver then fails the current communication and returns an error.
Delay before send	Some serial port hardware have a delay when enabling a data sending circuit after the RTS signal is turned on. Configure this option to wait a certain number of milliseconds after turning the RTS signal on and before sending the first byte. IMPORTANT: This delay must be used carefully, because it uses 100% of CPU resources while waiting. System's general performance degrades as this value increases.
Delay after send	This is the same effect of the Delay before send option, but in this case the delay is performed after sending the last byte, before turning the RTS signal off.

Ethernet Tab

Use this tab to configure parameters of an **Ethernet** Interface. These parameters, except port configurations, must also be configured for use in the **RAS**.

Ethernet

Transport: TCP/IP ▾

PING before connecting
 Timeout: 4000 ms
 Retries: 1

Listen for connections on port: 0

Share listen port with other processes

Interface: (All Interfaces) ▾

Use IPv6 Use SSL SSL Settings

Enable 'ECHO' suppression

IP Filter:

Connect to

<input type="checkbox"/> Main IP:		Port:	502	<input type="checkbox"/> Local port:	0
<input type="checkbox"/> Backup IP 1:		Port:	0	<input type="checkbox"/> Local port:	0
<input type="checkbox"/> Backup IP 2:		Port:	0	<input type="checkbox"/> Local port:	0
<input type="checkbox"/> Backup IP 3:		Port:	0	<input type="checkbox"/> Local port:	0

Ethernet tab

Available options on Ethernet tab

OPTION	DESCRIPTION
Transport	Select TCP/IP for a TCP socket (stream). Select UDP/IP to use a UDP socket (connectionless datagram)
Listen for connections on port	Use this option to wait for new connections in a specific IP port, common in Slave Drivers. If this option remains unselected, the Driver connects to the address and port specified in the Connect to option
Share listen port with other processes	Select this option to share the listen port with other Drivers and processes
Interface	Select the local network interface, identified by its IP address, that is used by the Driver to establish and receive connections, or select the (All Interfaces) item to use any local network interface
Use IPv6	Check this option to force the Driver to use IPv6 addresses on all Ethernet connections. If this option is unchecked the Driver will work with IPv4 addresses
Enable 'ECHO' suppression	Enable this option to remove the echo from received data. An echo is a copy of sent data, which can be returned before a reply message
IP Filter	List of restricted or allowed IP addresses from where a Driver accepts connections (Firewall). Please check the IO.Ethernet.IPFilter property for more details
PING before connecting	Enable this option to execute a ping command, that is, check whether a device can be reached on a network, for a device before trying a socket connection. This is a quick way of determining a successful connection before trying to

OPTION	DESCRIPTION
	<p>open a socket with a device. The time-out of a connection with a socket can be very high. The available options are:</p> <ul style="list-style-type: none"> • Timeout: Specify the number of milliseconds to wait for a reply from the ping command. Users must use the ping command to check the normal reply time, configuring this option for a value above that average. Usually this value can be configured between 1000 and 4000 milliseconds, that is, between one and four seconds • Retries: Number of retries of a ping command, not counting the first attempt. If all attempts fail, then the socket connection is aborted

Available options on the Connect to group

OPTION	DESCRIPTION
Main IP	Type the IP address of the remote device. Users can use an IP address separated by dots, as well as a URL. In case of a URL, the Driver uses the available DNS service to map that URL to an IP address, such as "192.168.0.13" or "Server1"
Port	Type the IP port of the remote device, between 0 (zero) and 65535
Local port	Select this option to use a fixed local IP port when connecting to a remote device
Backup IP 1, 2, and 3	Indicate here the IP address, the IP port, and the fixed local IP port of up to 3 (three) backup addresses of a remote device

General Configurations

This section contains information about the configuration of general **I/O Tags** and **Properties** of I/O Interfaces.

I/O Tags

General I/O Interfaces Tags (N2/B2 = 0)

The Tags described next are provided for all supported I/O Interfaces.

IO.IOKitEvent

Type of Tag	Block Tag
Type of Access	Read-Only
B1 Parameter	-1 (minus one)
B2 Parameter	0 (zero)
B3 Parameter	0 (zero)
B4 Parameter	1 (one)
Size Property	4 (four)
ParamItem Property	IO.IOKitEvent

This Block returns Driver events generated by several sources in I/O Interfaces. The **TimeStamp** property of this Block represents the moment this event occurred. The Block Elements are the following:

- **Element 0:** Type of event. Possible values are **0:** Information, **1:** Warning, or **2:** Error
- **Element 1:** Source of event. Possible values are **0:** Driver (specific of a Driver), **-1:** IOKit (generic events of I/O Interfaces), **-2:** **Serial** Interface, **-3:** **Modem** Interface, **-4:** **Ethernet** Interface, or **-5:** **RAS** Interface
- **Element 2:** Error number, specific for each source of event
- **Element 3:** Event message, a **String** specific for each event

NOTE

A Driver keeps a maximum number of 100 events internally. If additional events are reported, older events are discarded.

IO.PhysicalLayerStatus

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	2 (two)
String Configuration	IO.PhysicalLayerStatus

This Tag indicates the status of a physical layer. Its possible values are the following:

- **0:** Physical layer stopped, that is, the Driver is in **Offline** mode, the physical layer failed when initializing, or exceeded the maximum number of reconnection attempts
- **1:** Physical layer started but not connected, that is, the Driver is in **Online** mode but the physical layer is not connected. If the **Connection management** option is configured as **Automatic**, the physical layer can be connecting,

disconnecting, or waiting for a reconnection attempt. If the **Connection management** option is configured as **Manual**, then the physical layer remains in this status until forced to connect

- **2:** Physical layer connected, that is, the physical layer is ready for use. This **DOES NOT** mean the device is connected, only the access layer is working

IO.SetConfigurationParameters

Type of Tag	Block Tag
Type of Access	Read-Only
B1 Parameter	-1 (minus one)
B2 Parameter	0 (zero)
B3 Parameter	0 (zero)
B4 Parameter	3 (three)
Size Property	2 (two)
ParamItem Property	IO.SetConfigurationParameters

Use this Tag to change any property of a Driver's configuration dialog box at run time.

This Tag works only while a Driver is in **Offline** mode. To start a Driver in **Offline** mode, select the **Start driver OFFLINE** option on the Driver's configuration dialog box. Users can write to a PLC Tag or to a Block Tag containing the parameters to change. Writing individual Block Elements is not supported, the whole Block must be written at once.

In **Eclipse SCADA**, users must use a Block Tag. Every parameter to configure uses two Block Elements. For example, if users want to configure three parameters, then the size of the Block must be 6 (3 × 2). The first Element is the property's name, as a **String**, and the second Element is the property's value, according to the next example.

```
// 'Block' must be a Block Tag with automatic reading,
// scan reading, and automatic writing disabled.
// Configure all parameters
Block.element001 = "IO.Type" // Parameter 1
Block.element002 = "Serial"
Block.element003 = "IO.Serial.Port" // Parameter 2
Block.element004 = 1
Block.element005 = "IO.Serial.BaudRate" // Parameter 3
Block.element006 = 19200
// Writes the whole Block
Block.Write()
```

When using **E3**, the ability to create arrays at run time allows using an I/O Tag as well as a Block Tag. Users can use Driver's **Write** method to send all parameters to the Driver, without creating a Tag, according to the next example.

```
Dim arr(6)
' Configure all array elements
arr(1) = "IO.Type"
arr(2) = "Serial"
arr(3) = "IO.Serial.Port"
arr(4) = 1
arr(5) = "IO.Serial.BaudRate"
arr(6) = 19200
' There are two methods to send parameters
' Method 1: Using an I/O Tag
tag.WriteEx arr
' Method 2: Without using a Tag
Driver.Write -1, 0, 0, 3, arr
```

A variation of the previous example uses a bidimensional array.

```
Dim arr(10)
' Configure all array elements. Notice the array was resized
' to 10 elements. Empty array elements are ignored by a Driver
arr(1) = Array("IO.Type", "Serial")
arr(2) = Array("IO.Serial.Port", 1)
arr(3) = Array("IO.Serial.BaudRate", 19200)
Driver.Write -1, 0, 0, 3, arr
```

A Driver does not validate parameter names or passed values, therefore be careful when writing parameters and values. The **Write** method fails if the configuration array is incorrectly created. Users can check Driver's log or use the *writeStatus* parameter of the **WriteEx** method to find out the exact cause of the error.

```
Dim arr(10), strError
arr(1) = Array("IO.Type", "Serial")
arr(2) = Array("IO.Serial.Port", 1)
arr(3) = Array("IO.Serial.BaudRate", 19200)
If Not Driver.WriteEx -1, 0, 0, 3, arr, , , strError Then
    MsgBox "Failed configuring Driver parameters: " + strError
End If
```

IO.WorkOnline

Type of Tag	I/O Tag
Type of Access	Reading or Writing
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	4 (four)
String Configuration	IO.WorkOnline

This Tag informs the current status of a Driver and allows starting or stopping the physical layer. Possible values are the following:

- **0 - Driver Offline:** Physical layer is closed or stopped. This mode allows a dynamic configuration of a Driver's parameters using the **IO.SetConfigurationParameters** Tag
- **1 - Driver Online:** Physical layer is open or executing. While in **Online** mode, the physical layer can be connected or disconnected and its current status can be checked on the **IO.PhysicalLayerStatus** Tag

In the next example, using **E3**, a Driver is configured to **Offline** mode, its COM port is changed, and then configured to **Online** mode again.

```
'Configure to Offline mode
Driver.Write -1, 0, 0, 4, 0
'Change port to COM2
Driver.Write -1, 0, 0, 3, Array("IO.Serial.Port", 2)
'Configure to Online mode
Driver.Write -1, 0, 0, 4, 1
```

The **Write** method can fail when configuring a Driver to **Online** mode, that is, writing the value 1 (one). In this case, the Driver remains in **Offline** mode. The cause of failure can be:

- Type of physical layer incorrectly configured, probably an invalid value was configured in the **IO.Type** property

- Driver may have run out of memory
- Physical layer probably did not create its working thread. Search the log file for a message "Failed to create physical layer thread!"
- Physical layer could not start. The cause of failure depends on the type of physical layer. It can be an invalid serial port number, a failure when starting Windows Sockets, or a failure when starting TAPI (modem), among others. This cause is recorded on the log file

IMPORTANT

Even if the configuration of a Driver to **Online** mode is successful, this does not necessarily mean the physical layer is ready to use, that is, ready to execute input and output operations with an external device. The **IO.PhysicalLayerStatus** Tag must be checked to ensure the physical layer is connected and ready for communication.

Properties

These are general properties of all supported I/O Interfaces.

IO.ConnectionMode

9 Controls the management mode of a Connection. Possible values are **0**: Automatic mode, where a Driver manages the connection or **1**: Manual mode, where an application manages the connection.

IO.GiveUpEnable

☑ When configured to True, defines a maximum number of reconnection attempts. If all reconnection attempts fail, the Driver enters the **Offline** mode. When configured to False, the Driver tries until a reconnection is successful.

IO.GiveUpTries

9 Number of reconnection attempts before this one is aborted. For example, if the value of this property is equal to 1 (one), a Driver tries only one reconnection when the reconnection is lost. If this one fails, a Driver enters the **Offline** mode.

IO.InactivityEnable

☑ Configure to True to enable and to False to disable inactivity detection. The physical layer is disconnected if inactive for a certain period of time. The physical layer is considered inactive only if it is capable of sending data but not capable of receiving it back.

IO.InactivityPeriodSec

9 Number of seconds to check for inactivity. If the physical layer is inactive for this period of time, it is disconnected.

IO.RecoverEnable

☑ Configure to True to enable a Driver to recover lost connections and to False to leave a Driver in **Offline** mode when a connection is lost.

IO.RecoverPeriodSec

9 Delay time between two connection attempts, in seconds.

NOTE

The first reconnection is executed immediately after a connection is lost.

IO.StartOffline

☑ Configure to True to start a Driver in **Offline** mode and to False to start a Driver in **Online** mode.

NOTE

It is pointless to change this property at run time, as it can only be changed when a Driver is already in **Offline** mode. To configure a Driver in **Online** mode at run time, write the value 1 (one) to the **IO.WorkOnline** Tag.

IO.TimeoutMs

9 Defines a time-out for the physical layer, in milliseconds. One second is equal to 1000 milliseconds.

IO.Type

A Defines the type of physical interface used by a Driver. Possible values are the following:

- **N or None:** Does not use a physical interface, that is, a Driver must provide a customized interface
- **S or Serial:** Uses a local serial port (COM n)
- **M or Modem:** Uses a local modem, internal or external, accessed via TAPI (*Telephony Application Programming Interface*)
- **E or Ethernet:** Uses a TCP/IP or UDP/IP socket
- **R or RAS:** Uses a **RAS** (*Remote Access Server*) Interface. A Driver connects to a RAS device using the **Ethernet** Interface and then sends an **AT** (*dial*) command

Statistical Configuration

This section contains information about the configuration of **I/O Tags** and **Properties** of I/O Interfaces statistics.

I/O Tags**Tags of I/O Interface statistics (N2/B2 = 0)**

The Tags described next display statistics for all I/O Interfaces.

IO.Stats.Partial.BytesRecv

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1101
Configuration by String	IO.Stats.Partial.BytesRecv

This Tag returns the number of bytes received in the current connection.

IO.Stats.Partial.BytesSent

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1100
Configuration by String	IO.Stats.Partial.BytesSent

This Tag returns the number of bytes sent through the current connection.

IO.Stats.Partial.TimeConnectedSeconds

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1102
Configuration by String	IO.Stats.Partial.TimeConnectedSeconds

This Tag returns the number of seconds a Driver is connected in the current connection or 0 (zero) if a Driver is disconnected.

IO.Stats.Partial.TimeDisconnectedSeconds

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1103
Configuration by String	IO.Stats.Partial.TimeDisconnectedSeconds

This Tag returns the number of seconds a Driver is disconnected since the last connection ended or 0 (zero) if a Driver is connected.

IO.Stats.Total.BytesRecv

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1001
Configuration by String	IO.Stats.Total.BytesRecv

This Tag returns the number of bytes received since a Driver was loaded.

IO.Stats.Total.BytesSent

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1000
Configuration by String	IO.Stats.Total.BytesSent

This Tag returns the number of bytes sent since a Driver was loaded.

IO.Stats.Total.ConnectionCount

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1004
Configuration by String	IO.Stats.Total.ConnectionCount

This Tag returns the number of connections a Driver already established, successfully, since it was loaded.

IO.Stats.Total.TimeConnectedSeconds

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1002
Configuration by String	IO.Stats.Total.TimeConnectedSeconds

This Tag returns the number of seconds a Driver remained connected since it was loaded.

IO.Stats.Total.TimeDisconnectedSeconds

Type of Tag	I/O Tag
Type of Access	Read-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	0 (zero)
N4 Parameter	1003
Configuration by String	IO.Stats.Total.TimeDisconnectedSeconds

This Tag returns the number of seconds a Driver remained disconnected since it was loaded.

Properties

Currently, there are no properties defined specifically to display I/O Interface statistics at run time.

Ethernet Interface Configuration

This section contains information about the configuration of **I/O Tags** and **Properties** of an **Ethernet** Interface.

I/O Tags

Tags of an Ethernet Interface (N2/B2 = 4)

The Tags described next allow controlling and identifying an **Ethernet** Interface at run time and they are also valid when the **RAS** Interface is selected.

IMPORTANT

These Tags are available **ONLY** while a Driver is in **Online** mode.

IO.Ethernet.IPSelect

Type of Tag	I/O Tag
Type of Access	Reading or Writing
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	4 (four)
N4 Parameter	0 (zero)
String Configuration	IO.Ethernet.IPSelect

Indicates the active IP address. Possible values are **0**: The main IP address is selected, **1**: The first alternative or backup IP address is selected, **2**: The second alternative or backup IP address is selected, or **3**: The third alternative or backup IP address is selected.

If the **Ethernet** or **RAS** Interface is connected, this Tag indicates which one of the four configured IP addresses is in use. If the Interface is disconnected, this Tag indicates which IP address is used first on the next connection attempt.

During the connection process, if the active IP address is not available, the I/O Interface tries to connect using the next alternative IP address. If the connection with the alternative IP address works, it is configured as the active IP address (automatic switchover).

To force a manual switchover, write values from 0 (zero) to 3 (three) to this Tag. This forces a reconnection with the specified IP address (**0**: Main IP address or **1, 2, 3**: Alternative IP address) if the Driver is currently connected. If the Driver is disconnected, this Tag configures the active IP address for the next connection attempt.

IO.Ethernet.IPSwitch

Type of Tag	I/O Tag
Type of Access	Write-Only
N1 Parameter	-1 (minus one)
N2 Parameter	0 (zero)
N3 Parameter	4 (four)
N4 Parameter	1 (one)
String Configuration	IO.Ethernet.IPSwitch

Any value written to this Tag forces a manual switchover. If the main IP address is active, then the Driver tries to connect to each one of the alternative or backup IP addresses and back to the main IP address until a connection is established.

If the Driver is disconnected, this Tag configures the active IP address for the next connection attempt.

Properties

These properties control the configuration of an **Ethernet** Interface.

NOTE

The **Ethernet** Interface is also used by the **RAS** Interface.

IO.Ethernet.AcceptConnection

☑ Configure to False if the Driver must not accept external connections, that is the Driver behaves as a master, or configure to True to enable the reception of connections, that is, the Driver behaves as a slave.

IO.Ethernet.BackupEnable[2,3]

☑ Configure to True to enable an alternative or backup IP address. If the reconnection attempt with the main IP address fails, the Driver tries to use an alternative IP address. Configure to False to disable its usage.

IO.Ethernet.BackupLocalPort[2,3]

9 Local port number to be used when connecting to an alternative IP address of a remote device. Used only if **IO.Ethernet.BackupLocalPortEnable** is equal to True.

IO.Ethernet.BackupLocalPortEnable[2,3]

☑ Configure to True to force the use of a specific local port when connecting to an alternative or backup IP address of a remote device or configure to False to use any available local port.

IO.Ethernet.BackupIP[2,3]

A Alternative or backup IP address of a remote device. Users can use a numerical address, as well as a device's host name, such as "192.168.0.7" or "SERVER2".

IO.Ethernet.BackupPort[2,3]

9 Port number of an alternative or backup IP address of a remote device, used with the **IO.Ethernet.BackupIP** property.

IO.Ethernet.IPFilter

A List with a comma-separated IPv4 or IPv6 addresses, which defines from which addresses a Driver accepts or blocks connections. Users can use asterisks, such as "192.168.*.*", or intervals, such as "192.168.0.41-50", in any part of IP addresses. To block an IP address or a range of IP addresses, use the tilde ("~") character at the beginning of the address. Examples:

- **192.168.0.24**: Accepts only connections from IPv4 address 192.168.0.24
- **192.168.0.41-50**: Accepts connections from IPv4 addresses from 192.168.0.41 to 192.168.0.50
- **192.168.0.***: Accepts connections from IPv4 addresses from 192.168.0.0 to 192.168.0.255
- **fe80:3bf:877:::* (expands to fe80:03bf:0877:0000:0000:0000:0000:0000 to fe80:03bf:0877:0000:0000:0000:ffff:ffff)**: Accepts connections from IPv6 addresses from fe80:03bf:0877:0000:0000:0000:0000:0000 to fe80:03bf:0877:0000:0000:0000:ffff:ffff
- **192.168.0.10, 192.168.0.15, 192.168.0.20**: Accepts connections from IPv4 addresses 192.168.0.10, 192.168.0.15, and 192.168.0.20
- **~192.168.0.95, 192.168.0.***: Accepts connections from IPv4 addresses from 192.168.0.0 to 192.168.0.255, except the IPv4 address 192.168.0.95

When a Driver receives a connection attempt, the list of filters is scanned sequentially from left to right, searching for a specific authorization or block for the IP address where the connection comes from. If no element on the list corresponds to the IP address, the authorization or block are dictated by the last element of that list:

- If the last element on the list is an authorization, such as "192.168.0.24", then all IP addresses not found on the list are blocked
- If the last element on the list is a block, such as "~192.168.0.24", then all IP addresses not found on the list are authorized

If an IP address appears on more than one filter on the list, the leftmost filter has precedence. For example, in case of "~192.168.0.95, 192.168.0.*", the IP address 192.168.0.95 fits both rules, but the rule that wins is the leftmost one, "~192.168.0.95", and therefore this IP address is blocked.

When **IOKit** blocks a connection, it logs a message "Blocked incoming socket connection from {IP}!".

In case of UDP connections in broadcast listen mode, where a Driver can receive packets from different IP addresses, blocks or permissions are performed at each packet received. If a packet is received from a blocked IP address, it logs a message "Blocked incoming packet from {IP} (discarding {N} bytes)!".

IO.Ethernet.ListenIP

A IP address of the local network interface that a Driver uses to establish and receive connections. Leave this property empty to use any local network interface.

IO.Ethernet.ListenPort

9 Number of the IP port used by a Driver to listen to connections.

IO.Ethernet.MainIP

A IP address of a remote device. Users can use a numerical address, as well as a device's host name, such as "192.168.0.7" or "SERVER2".

IO.Ethernet.MainLocalPort

9 Local port number to use when connecting to the main IP address of a remote device. This value is only used if the **IO.Ethernet.MainLocalPortEnable** property is equal to True.

IO.Ethernet.MainLocalPortEnable

Configure to True to force the use of a specific local port when connecting to the main IP address of a remote device or configure to False to use any available local port.

IO.Ethernet.MainPort

9 Number of the IP port of a remote device, used with the **IO.Ethernet.MainIP** property.

IO.Ethernet.PingEnable

Configure to True to enable sending a **ping** command to the IP address of a remote device, before trying to connect to the socket. This socket's connection time-out cannot be controlled, therefore sending a **ping** command before connecting is a fast way to detect if the connection is going to fail. Configure to False to disable a **ping** command.

IO.Ethernet.PingTimeoutMs

9 Delay time to wait for a response from a **ping** command, in milliseconds.

IO.Ethernet.PingTries

9 Maximum number of attempts of a **ping** command. Minimum value is 1 (one), including the first **ping** command.

IO.Ethernet.ShareListenPort

☑ Configure to True to share a listening port with other Drivers and processes or False to open a listening port in exclusive mode. To successfully share a listening port, all Drivers and processes that use that port must open it in shared mode. When a listening port is shared, each incoming connection is distributed to one of the processes listening. This way, if a Slave Driver only supports one connection at a time, users can use several instances of this Driver listening on the same port, therefore simulating a Driver with support for multiple connections.

IO.Ethernet.SupressEcho

☑ Configure to True to eliminate echoes in communication. An echo is the unwanted reception of an exact copy of all data packets a Driver sends to a device.

IO.Ethernet.Transport

⚠ Defines a transport protocol. Possible values are **T or TCP**: Uses the TCP/IP protocol or **U or UDP**: Uses the UDP/IP protocol.

IO.Ethernet.UseIPv6

☑ Configure to True to use IPv6 addresses on all Ethernet connections or configure to False to use IPv4 addresses (default).

Serial Interface Configuration

This section contains information about the configuration of **I/O Tags** and **Properties** of a **Serial** Interface.

I/O Tags

Tags of a Serial Interface (N2/B2 = 2)

Currently, there are no Tags defined specifically to manage a **Serial** Interface at run time.

Properties

These properties control the configuration of a **Serial** Interface.

IO.Serial.Baudrate

9 Specifies a baud rate of a serial port, such as 9600.

IO.Serial.CTSTimeoutMs

9 Time to wait for a **CTS** signal, in milliseconds. After turning the **RTS** signal on, a timer is started to wait for a **CTS** signal. If this timer expires, the Driver aborts sending bytes through the serial port. Available only when the **IO.Serial.RTS** property is configured as **Toggle** and the **IO.Serial.WaitCTS** property is configured to True.

IO.Serial.DataBits

9 Specifies the number of data bits to configure a serial port. Possible values are **5**: Five data bits, **6**: Six data bits, **7**: Seven data bits, or **8**: Eight data bits.

IO.Serial.DelayAfterMs

9 Number of milliseconds to delay after the last byte is sent through a serial port, but before turning the **RTS** signal off. Available only when the **IO.Serial.RTS** property is configured to **Toggle** and the **IO.Serial.WaitCTS** property is configured to **False**.

IO.Serial.DelayBeforeMs

9 Number of milliseconds to delay after turning the **RTS** signal on, but before data is sent. Available only when the **IO.Serial.RTS** property is configured to **Toggle** and the **IO.Serial.WaitCTS** property is configured to **False**.

IO.Serial.DTR

A Indicates how a Driver deals with the **DTR** signal. Possible values are **OFF**: **DTR** signal is always turned off or **ON**: **DTR** signal is always turned on.

IO.Serial.InterbyteDelayUs

9 Delay time, in milliseconds (1/1000000 of a second), for each two bytes sent through a **Serial** Interface.

IO.Serial.InterframeDelayMs

9 Delay time, in milliseconds, before sending a packet after the last packet sent or received.

IO.Serial.Parity

A Specifies a parity for the configuration of a serial port. Possible values are **E or Even**: Even parity, **N or None**: No parity, **O or Odd**: Odd parity, **M or Mark**: Mark parity, or **S or Space**: Space parity.

IO.Serial.Port

9 Number of the local serial port. Possible values are **1**: Uses the COM1 port, **2**: Uses the COM2 port, **3**: Uses the COM3 port, or **n**: Uses the COMn port.

IO.Serial.RTS

A Indicates how a Driver deals with the **RTS** signal. Possible values are **OFF**: **RTS** signal always off, **ON**: **RTS** signal always on, or **Toggle**: Turns the **RTS** signal on when transmitting data and turns the **RTS** signal off when not transmitting data.

IO.Serial.StopBits

9 Specifies the number of stop bits for the configuration of a serial port. Possible values are **1**: One stop bit, **2**: One and a half stop bit, or **3**: Two stop bits.

IO.Serial.SuppressEcho

9 Use a value different from 0 (zero) to enable suppressing the echo or 0 (zero) to disable it.

IO.Serial.WaitCTS

☑ Configure to True to force a Driver to wait for the **CTS** signal before sending bytes when the **RTS** signal is turned on. Available only when the **IO.Serial.RTS** property is configured to **Toggle**.

Driver Revision History

VERSION	DATE	AUTHOR	COMMENTS
3.0.2	06/18/2021	M. Ludwig	<ul style="list-style-type: none"> Added support for Ethernet physical layer again (Case 31042).
3.0.1	08/08/2019	M. Ludwig	<ul style="list-style-type: none"> Driver ported to Visual Studio 2017 (Case 27094).
2.1.1	09/06/2012	G. Taschetto	<ul style="list-style-type: none"> Added documentation notes (Case 12733). Driver updated to IOKit v1.15.
2.0.1	11/01/2005	M. Ludwig	<ul style="list-style-type: none"> Driver ported to IOKit (Case 5672).
1.1.1	07/12/2005	A. Quites	<ul style="list-style-type: none"> Fixed an error that allowed sending a [BEGIN] token from the first label to the printer in case there were empty or commented lines before that token (Case 5855). Version tested with EPL II language (Case 5547). Implemented support for Strings as values for internal variables (Case 5547). Fixed a problem preventing the opening of the ZPL II Configuration window on this Driver's extra settings when using E3 (Case 5881). Other updates regarding the latest DDK.
1.0.1	11/28/2003	A. Quites	<ul style="list-style-type: none"> Driver's original version.

Headquarters

**Rua Mostardeiro, 322/Cj. 902, 1001 e
1002**

90510-002 — Porto Alegre — RS

Phone: (+55 51) 3346-4699

Fax: (+55 51) 3222-6226

E-mail: elipse-rs@elipse.com.br

Branch in Taiwan

9F., No.12, Beiping 2nd St., Sanmin Dist.

807 — Kaohsiung City — Taiwan

Phone: (+886 7) 323-8468

Fax: (+886 7) 323-9656

E-mail: evan@elipse.com.br

Check our website for information about a representative in your country.


www.elipse.com.br

kb.elipse.com.br

forum.elipse.com.br

www.youtube.com/elipsesoftware

elipse@elipse.com.br



Gartner, Cool Vendors in Brazil 2014, April 2014.

Gartner does not endorse any vendor, product or service depicted in its research publications, and does not advise technology users to select only those vendors with the highest ratings. Gartner research publications consist of the opinions of Gartner's research organization and should not be construed as statements of fact. Gartner disclaims all warranties, expressed or implied, with respect to this research, including any warranties of merchantability of fitness for a particular purpose.

Microsoft Partner
Gold Independent Software Vendor (ISV)